

## FURON® FASTFLARE™ FORMING TOOL



Furon FastFLARE forming tools are ideal for cold flaring PFA tubing. For use with Furon Flare Grip® and Flare Grip II PFA fittings.

### Ordering Information

PART NO.	DESCRIPTION
1101021	1/4" (6.35mm)
1101022	3/8" (9.53mm)
1101023	1/2" (12.7mm)
1101024	3/4" (19.5mm)
1101025	1" (25.4mm)



Furon® is a registered trademark.  
FastFLARE™ is a trademark.  
Flare Grip® is a registered trademark.

Saint-Gobain Performance Plastics - France 56,  
Chemin des Berthilliers  
71850 Charnay-lès-Mâcon, France

授權代理經銷商：  
宏騏科技有限公司  
TEL: 886-3-5631221  
FAX: 886-3-5631222  
Email: Sales@honkey.com.tw

### Usage Guide

1. Install nut on tubing
2. Insert flaring tool spreader tip all the way into the end of the tube
3. Maintain insertion pressure while lightly squeezing the flaring tool to expand the spreader tip
4. Relax squeezing pressure and rotate tube slightly
5. Repeat step 2 several times, progressively increasing pressure until maximum spreading expansion is reached

### Note:

1. Tubing will be pushed off the spreader tip slightly each time
2. It is critical to repeat and rotate the expanding/spreading process several times to ensure proper flaring

